
Box: PLOCK 1

	1		
BIKE	SUZUKI SV 650	PART NO.	ESI - 75
YEAR	03	FIT KITS	OVAL Z039.11082 // ROUND Z039.10082
NOTES	Item 7 required to re-fit OE exhaust system	FEATURES	DB KILLER Z038.10120



- 1 450mm Silencer ESC 94
- 2 51-55mm Band Clamp (Z016.10002)
- 3 Composite Silencer Strap (R-Z038.10089)(O-Z038.10088)
- 4 2 x M8 x 25mm Washers (Z017.10825)
- 5 Connecting Pipe CP 325
- 6 55-59mm Band Clamp (Z016.10004)
- 7 Re-connecting Sleeve CP327

8 Original Silencer Cut Diagram

E-MARK	SCDB-UC e4 2106	
ISSUE NO.	13	
DATE	07/08/09	
AUTHORISED	S.Northrop	
CHECKED		

NOTE: ENSURE SCORPION SYSTEM IS CLEAR OF MOVING PARTS AND ALL ORIGINAL FUNCTIONS WORK CORRECTLY.



- A) Remove original exhaust from bike, taking care to keep all original components in a safe place.
- B) Refit Scorpion exhaust as per line diagram above.
- C) When fitted take bike for a short ride to ensure all functions are correct.
- D) When bike & exhaust are cool enough check all nuts and bolts are still secure.

